



MoniServ, Inc.


<http://www.moniserv.com>

<http://www.lcdpart.com>


Backlight Inverter Installation Procedures for IBM 6657-HG2




Use Small Flat Head screw driver to remove this plastic cover by Pull it down



Unscrews 6 screws and remove back cover







Replace with MoniServ K021036.00MSS Backlight Inverter. Reinstall all components back.